Technical Reference

DASHER<sup>®</sup> DISPLAY TERMINALS 6052, 6053

014-000077-01

## NOTICE

Data General Corporation (DGC) has prepared this manual for use by DGC personnel and customers as a guide to the proper installation, operation, and maintenance of DGC equipment and software. The drawings and specifications contained herein are the property of DGC and shall neither be reproduced in whole or in part without DGC prior written approval nor be implied to grant any license to make, use, or sell equipment manufactured in accordance herewith.

DGC reserves the right to make changes without notice in the specifications and materials contained herein and shall not be responsible for any damages (including consequential) caused by reliance on the materials presented, including but not limited to typographical or arithmetic errors, company policy and pricing information. The information contained herein on DGC software is summary in nature. More detailed information on DGC software is available in current released publications.

NOVA, SUPERNOVA and ECLIPSE are registered trademarks of Data General Corporation, Westboro, Massachusetts. DASHER is a trademark of Data General Corporation, Westboro, Massachusetts.

> Ordering No. 014-000077 ©Data General Corporation, 1977 All Rights Reserved Printed in the United States of America Rev. 01, September 1977

# **TABLE OF CONTENTS**

## INTRODUCTION TO DASHER DISPLAY TERMINALS MODELS 6052, 6053

INTRODUCTION 6054/6055 Printer Options ARCHITECTURE **OVERVIEW OF THEORY OF OPERATION** The Keyboard **Asynchronous Interface** Transmit Keyboard Data **Transmit Cursor Address Receive Computer Data Control Logic** Memory Video Timing and Character Generator **Video Timing Generator Video Character Generator** Video Monitor 6054/6055 Printer Option

## **PROGRAMMER'S REFERENCE**

## INTRODUCTION

Keyboard

**User Function Codes** 

Display

Character Blinking Character Dimming/Underscoring

Character Dimining, Chactor

Screen Rolling

**Cursor Addressing** 

**Cursor Sensing** 

**CHAPTER ||** ||-1 ||-1 ||-2 ||-2 ||-2 ||-2

CHAPTER

1-1

1-2

1-3

1-3

1-4

1-4 1-4

1-4

1-4 1-5

1-6

1-8 1-8

1-8

1-9

1-9

## **TABLE OF CONTENTS (Continued)**

DISPLAY COMMANDS INSTRUCTIONS Read Character Buffer Load Character Buffer PROGRAMMING Input Output TIMING CONSIDERATIONS Input Output PROGRAMMING EXAMPLES Cursor Address Codes User Function Codes Print and Print Form Codes Program Interrupt

11-3

11-6 11-6

11-6

11-7

11-7

11-7

ll-7 11-7

11-7

11-8 11-9

11-10 11-10

11-11

111-1

III-1 111-2

111-2

111-3

111-3

111-4

111-4

111-4

111-4

111-4 111-4

111-4

111-4

111-4

111-5

111-5

111-5

CHAPTER III

## **OPERATOR CONTROLS AND PROCEDURES**

INTRODUCTION DISPLAY **KEYBOARD** Main Keypad Numeric Keypad Screen Management Keypad **User Function Keypad DISPLAY EXTERNAL CONTROLS** Front Panel **Power ON/OFF and Screen Brightness Rear Panel Data Rate** Parity Mode Screen **OPERATING NOTE CLEANING PREVENTIVE MAINTENANCE** 

Data General Corporation (DGC) has prepared this manual for use by DGC personnel and customers as a guide to the proper installation, operation, and maintenance of DGC equipment and software. The drawings and specifications contained herein are the property of DGC and shall neither be reproduced in whole or in part without DGC's prior written approval nor be implied to grant any license to make, use, or sell equipment manufactured in accordance herewith.

## TABLE OF CONTENTS (Continued)

## APPENDICES

A-1

A-1

A-2

A-3

A-5

A-7

B-1


8-1

#### **APPENDIX** A

- **ASCII Character Codes with Terminal Control Functions** 
  - ASCII Character Codes Plotted by the 6052 Terminal
- ASCII Character Codes Plotted by the 6053 Terminal
- **Display Commands**
- Protocol Characters

## **APPENDIX B**

Code Sequences Generated by the User Function Keypad



DG-03834

•

#### COMPONENT

- 1. CRT DISPLAY, MODELS 6052, 6053 2. KEYBOARD, MODEL 6052
- 3. KEYBOARD, MODEL 6053

## CHAPTER I INTRODUCTION TO DASHER DISPLAY TERMINALS MODELS 6052, 6053

## INTRODUCTION

Data General's DASHER 6052/6053 display terminals are soft-copy I/O devices, designed for use in a wide range of interactive terminal applications. Model 6052 is the basic, upper case ASCII terminal; model 6053 is enhanced, upper/lower case ASCII terminal. Both models operate in full-duplex mode only.


The display terminals consist of two units: an alphanumeric CRT display that is mounted on a fully articulated base and a separate, solid state, capacitive switching keyboard. The units are connected by a 4 foot, plug -in, external cable attached to the keyboard. Online, the display and keyboard function independently while sharing a common asynchronous interface to communicate with the computer. The keyboard is a transmit-only device. The display is a receive-only device with the additional capability of transmitting cursor position information when requested.

Communication with the computer is via either a 20mA current loop or an EIA RS-232C communications line. Both the rate at which data is transmitted and the type of parity check are externally switch-selectable on the display's accessory panel. Data transmission rates range from 110 baud to 19.2K baud. Parity may be either even, odd or marking.

The CRT display has a 1920-character, dynamic RAM memory and a non-interlaced video monitor with a 12 inch diagonal screen. The screen has an active area of 8.5 inches by 5.5 inches, formatted as 24 lines, 80 characters per line. A non-destructive cursor is displayed on the screen as a blinking underscore. Printing characters received by the display are stored in memory and displayed on the screen as either 5x7 upper case dot matrices or 5x8 lower case dot matrices.

Using display command codes, characters can be blinked on a character by character basis, the cursor can be directly addressed or sensed, and the screen can be rolled up one line at a time. On the model 6053, characters can also be displayed at reduced intensity (dimmed) and/or underscored on a character by character basis.


The keyboard of the 6052 display terminal has a teletypewriter-style main keypad while the 6053 keyboard has a typewriter-style main keypad. Both keyboards have three supplementary keypads: numeric, screen management and user function. See the keyboard illustrations on the following page. The user function keys expand the capabilities of these terminals. Model 6052 generates 32 and model 6053 generates 44 user-defined codes with which the programmer can implement his application.



## 6054/6055 Printer Options

Two video enhancement packages are offered with the DASHER 6052/6053 display terminals which provide facilities for hardcopy output of information displayed on the CRT screen.


The first, model 6054, consists of a printed circuit board, housed in the display chassis, which communicates with any ASCII-based printer with an EIA RS-232C interface. Data transmission rates range from 110 to 1200 baud. An internal cable and an



external EIA RS-232C connector are also included with the model 6054 printer option.

The second, model 6055, consists of the printed circuit board, an internal cable, an external cable and a model 6041 DASHER Receive-Only (RO) 60 cps printer.

The screen formatting capability of the model 6053, implemented through the dimming feature, combined with either of the above printer options allows the use of preprinted forms.



## ARCHITECTURE

The 6052/6053 display terminals incorporate a modular design that facilitates maintenance and provides high reliability. This modularity allows the 6052 terminal to be easily upgraded to a model 6053.

Both terminals consist of the following main assemblies:


- A keyboard and an external cable.
- An alphanumeric CRT display consisting of the following subassemblies:
  - An accessory panel containing the following: a receptacle for the keyboard external cable; a data rate rotary switch; a parity slide switch; an online/local mode slide switch; interface connections for a 20mA current loop, an EIA RS-232C communications line, and a printer; and a composite video output jack.
  - An asynchronous interface, which forms the communications link between the keyboard, the computer and the display.
  - Control logic, which decodes the characters received via the asynchronous interface, controls the information written into

memory including character blinking, dimming and underscoring, and maintains cursor and memory addresses.

- A video timing and character generator, which provides the system timing and generates the signals necessary to display the printing characters on the screen of the video monitor.
- A 1920-character dynamic RAM memory which stores the information displayed on the screen.
- A video monitor that displays the information stored in memory.
- A power supply, which provides power for the unit.

## OVERVIEW OF THEORY OF OPERATION

The 6052/6053 DASHER display terminals transmit and respond to a subset of the 128-ASCII character set listed in Appendix A. As described previously, both terminals consist of two I/O devices, a keyboard and a display, which function independently when operating online with the computer. A simplified block diagram of the operation of these terminals is shown below.



## The Keyboard


When the operator strikes a key on either the main, screen management or numeric keypad, the appropriate ASCII character code is transmitted to the computer. When the operator strikes a user function key, a sequence of two codes is sent to the computer. The first code is the ASCII control character, Record Separator ( $036_8$ ). This code, referred to as the user function header code, notifies the executing program that the next code received should be interpreted as a user-defined code. The second code is one of the ASCII characters listed in Appendix B.

The hardware of the keyboard and the asynchronous interface identifies the type of code generated by the keyboard, standard data or user function, and transmits the appropriate code, or sequence of two codes, in the following manner. The keyboard converts each keystroke into an 8-bit code consisting of a 7-bit ASCII character code and a user function bit. A user function key, when struck, generates a 1 in this bit; all other keys generate a 0. These 8-bit codes are sent to the asynchronous interface via a 4 foot external cable connected to the display's accessory panel.

## **Asynchronous Interface**

All information transfers between the keyboard, the computer and the CRT display are via the asynchronous interface. The rate at which data is transmitted is determined by the setting of the data rate rotary switch on the accessory panel.

The asynchronous interface transmits and responds to 10-bit serial codes (or 11-bit codes when operating at 110 baud) containing 7 data bits and 1 parity bit. The parity computation for data received from the computer must be the same as that selected for the display terminal by the setting of the parity switch on the accessory panel.



#### Transmit Keyboard Data


As each keyboard code is received by the asynchronous interface, the user function bit is tested and then stripped from the code. If it is not a user function code, the multiplexor (refer to the asynchronous interface block diagram) passes the remaining 7-bit ASCII character to a transmitter. If it is, the multiplexor sends the user function header code,  $036_8$ , to the transmitter, followed by the 7-bit ASCII character, thus providing the two-code, user-function sequence. The transmitter responds to each code received by performing the selected parity computation, adding the parity bit and the start and stop bits, and transmitting the resulting serial code to the computer via either the 20mA current loop or EIA RS-232C communications line.

#### Transmit Cursor Address

The current position of the cursor is requested by sending a Read Cursor Address code to the display (see Display Commands in Chapter II). When this occurs, the multiplexor sends a cursor address header code (Unit Separator,  $037_8$ ) to the transmitter. The multiplexor is then temporarily disabled by the priority encoder/decoder while two codes, consisting of the cursor's 7-bit column and 5-bit row address, respectively, are sent from the display control logic to the transmitter. Thus, a three-code sequence is sent to the computer. The cursor header code notifies the executing program that the next two codes should be interpreted as the cursor's horizontal and vertical coordinates, respectively.

#### **Receive Computer Data**

As each code is received from the computer, the receiver performs the following functions: it checks for parity and framing errors; strips the parity, start and stop bits from the code; performs a serial to parallel conversion; and passes the parallel code, together with the appropriate error signals, to the error detection logic. If the code is received error-free, it passes to the display's data bus. If the code contains a parity or framing error, it is converted to a code containing all ones and then passes to the data bus. This code is displayed on the model 6052 terminal screen as a question mark and on the model 6053 terminal screen as a 5x7 block with all dots intensified. A Delete character,  $177_8$ , decoded by the error detection logic is ignored.




## **Control Logic**

The control logic decodes each code as it appears on the data bus to ascertain if the code is a printing character to be displayed on the screen or if it is a control character. When an ASCII printing character is decoded, the memory function control logic (refer to the control logic block diagram) generates the proper signals to enable the code on the data bus to be written into memory. It also enables the memory address multiplexor to pass the cursor address to the memory address bus. When a control character is decoded, it is sent to three ROMs for decoding. If it is a display command, the ROMs generate the appropriate signal(s) to carry out the command; if it is not, the code is ignored.

The control logic maintains cursor and memory addresses in counter/registers. These registers provide the memory addresses used during memory write operations. During read operations, the cursor address is compared to the video address appearing on the memory address bus.


The contents of the cursor address registers can be altered or read when the appropriate commands are sent to the display. The contents can be altered in two ways: either by commands which move the cursor relative to its current position (e.g., Cursor Up, Cursor Left) or by a Write Cursor Address command. When the latter is decoded, the next two codes appearing on the data bus are directed to the cursor address registers. The first code is parallel loaded into the cursor's 7-bit column register and the low order five bits of the second code are loaded into its 5-bit row register. The contents are read when a Read Cursor Address command code is sent to the display. When this code is received, two codes containing the cursor's 7-bit column and 5-bit row address, respectively, are sent to the asynchronous interface.

Five flags, Blink, Blink Inhibit, Dim, Underscore, and Roll Screen Enable, reside on the control logic board. These flags are set by display commands. Signals which reflect the state, 0 or 1, of the Blink flag and the Dim and Underscore flags (6053 terminal only) are sent to memory. The state of the Blink Inhibit flag is sent to the video timing and character generator and the state of the Roll flag is sent to the memory function control. When the display is roll enabled by the setting of this flag, the memory function control generates a signal which updates the memory row addresses on the memory board. This causes the information on the screen to roll up one line each time the cursor overflows the bottom line or a New Line code is decoded when the cursor is on the bottom line.



#### Memory

The memory provides storage for 1920 characters. These characters are stored in seven 2K dynamic RAMs in the 6052 terminal and in ten 2K dynamic RAMs in the 6053 terminal. Each memory location in the 6052 terminal provides storage for a 6-bit character code (1 bit is dropped from the code when it is stored in memory) plus the blink bit. The 6053 terminal provides storage for a 7-bit character code plus the blink, dim, and underscore bits. Memory writing is initiated by signals received from the control logic. When a character is written into the 6052 terminal memory, the signal reflecting the state of the Blink flag is sampled and written into the blink bit of that memory location. When a character is written into the 6053 terminal memory, the signals reflecting the state of the Blink, Dim and Underscore flags are sampled and written into the blink, dim and underscore bits of that memory location. In this way, the blink, dim and underscore attributes (on or off) become an integral part of each character stored in memory. Memory reading is initiated by signals received from the video timing and character generator, which also provides the memory addresses. Eighty characters (one line) are read at a time and are passed to the video timing and character generator via the memory data bus. The roll mode base line register (refer to the memory block diagram) updates the memory row addresses at the appropriate time when the Roll Screen Enable flag is set.



### Video Timing and Character Generator

This printed circuit board consists of a video timing generator and a video character generator.


#### Video Timing Generator

A 22.932MHz crystal oscillator and a group of counters produce the timing signals which control the operation of the display unit. In addition, the video timing logic generates the horizontal/vertical sync and dimming signals, the cursor blink rate and the character blink rate sent to the video monitor and the video addresses sent to memory during read operations.


#### **Video Character Generator**

As memory is read, the information on the memory data bus is loaded into an 80-character recirculating shift register in the video character generator. During this time the memory addresses are compared with

the cursor address to determine if the cursor will appear on the next line of characters to be displayed. Information in the recirculating shift register is read one scan at a time (see the description of the video monitor) and passed either to an upper case dot generator ROM in the 6052 terminal or to the appropriate upper and lower case dot generator ROMs in the 6053 terminal. In the 6052 terminal, the character codes are manipulated in such a way that lower case characters received by this terminal are converted to their upper case equivalents. The output of the dot generator ROM(s) is sent to a shift register. The serial output of this register provides the proper signal to display upper case character codes as 5x7 dot matrices and lower case as 5x8 dot matrices on the CRT screen. The signal reflecting the state of the Blink Inhibit flag is sent to the shift register. If blinking is enabled, the characters whose blink bit contains a one are blinked on the screen; if blinking is inhibited, none of the characters displayed on the screen are blinked. In the 6053 terminal, characters whose dim and/or underscore bits are set to 1 are dimmed and/or underscored, respectively.



- VIDEO AND CHARACTER GENERATOR -



## **Video Monitor**

The video monitor is the display's output, providing a visual image of each character stored in memory. The monitor's 12 inch diagonal screen has an active area of 8.5 inches by 5.5 inches with a margin at the top, bottom and both sides. It displays alphanumeric characters as dot matrices by using a pattern of lines traced with an electron beam.

The monitor is a magnetically deflected device which uses a non-interlaced raster pattern of scanning. A raster is a system of parallel horizontal lines to display characters on the CRT screen. Discrete positions within the raster are defined in the video timing logic by a number of parameters: line, scan, character and dot positions.

The monitor receives horizontal and vertical synchronizing signals from the video timing logic. These signals synchronize and trigger electromagnetic deflection circuits which move the CRT's electron beam horizontally and vertically around the screen. The horizontal deflection circuit is triggered by a 15.6kHz signal while the vertical deflection circuit is triggered by a 50Hz or 60Hz signal. This combination of scanning frequencies produces 260 horizontal scans for each vertical scan.

The electron beam scans the screen to display 24 lines, 80 characters wide. Each line consists of 10 horizontal scans. As the monitor's electron beam makes each horizontal scan, it traces one slice of a line. These scans are divided into 80 character positions across the screen. Each character position is divided into 7 dot positions in which the electron beam is either intensified or held at a low intensity so that a visible trace does not appear on the screen. This scanning provides a character field made up of 7x10 distinct dots.


## 6054/6055 Printer Option

The 6054/6055 printer I/O controller transmits information stored in the display's memory to the printer in 10-bit serial form, or 11-bit form when operating at 110 baud. The rate at which information is transmitted is switch-selectable on the printed circuit board.

The printer controller transmits information beginning with the leftmost character of the line on which the cursor resides to the end of the screen. Column and line counters generate the addresses sent to memory during a print operation.

When a print command is received, a printer busy signal is sent to the asynchronous interface which disables the keyboard. The cursor line address is loaded into the line counter, the column counter is set to 0, and a Carriage Return and a Line Feed code are sent to the printer. Memory reading begins with the first scan of the cursor line. As information is read from memory, it is transmitted to the printer and the address counters are incremented appropriately. At the end of each line, a Carriage Return and a Line Feed code are transmitted. Trailing spaces at the end of lines are not transmitted. When all information has been sent, the controller sends a printer done signal to the asynchronous interface. This signal frees the keyboard and generates a printer done code ( $006_8$ ) which is transmitted to the computer.

When a print format command is sent to the 6053 terminal, the controller assumes format mode. In this mode, a character containing the dim attribute (dim bit is set to 1) is interpreted by the controller as a space and only a character whose dim bit is set to 0 is transmitted to the printer.



For more detailed information concerning the theory of operation, refer to the *Technical Manual*, 6052-6053 DASHER Display Terminals, DGC No. 015-000065.

## THE 6052, 6053 DISPLAY TERMINAL SPECIFICATIONS

## PROPERTIES

Mounting	Display dimensions: 12 5" X 14 5" X 20.5" Keyboard dimensions: 2 75" X 9" X 20" Display: 45 pounds Keyboard. 7 pounds 0 degC to 45 degC 10% to 95", non-condensing, c 10,000 feet maximum	± 2Hz) ± 2Hz) ± 2Hz) ± 2Hz)
SYSTEM CAPACITY	2207015, 50121	± 2⊓2)
Number of displays/system Display Information Capacity	1920 characters, formatted as	24 lines, ng area of 8.5 inches by 5.5 inches on
CHARACTERISTICS		
Data Transmission Mode Qata Transmission Type Code Format Parity Data Rate Interface	Asynchronous ASCII, 10 or 11-bit, serial Even, odd or mark, switch selectable 110 to 19 2K baud, switch selectable	
Keyboard	Model 6052	Model 6053
Main keypad style	Teletypewriter style with 4-foot external, plug-in cable to display	Typewriter stye, with 4 foot external, plug-in cable to display
Type Numeric keypad keys Screen management keypad keys User function keypad keys Character Set	Solid state capac 11 10 08 Model 6052	itive switching 11 12 11 Model 6053
	ASCII 64 upper case alphanumeric	ASCII 96 upper and lower case alphanumeric
International Fonts		
Display Program addressable cursor Blink Underscore Dim Roll Screen Enable	Character by character Model 6053 only, character by character Model 6053 only, character by character	
Video Monitor Type Screen size Character style	<ul> <li>8 5 inches by 5 5 inches viewing area, 12 inches diagonal</li> <li>Model 6052 5 X 7 dot matrix</li> </ul>	
Display	P4 White Magnetic	

This page intentionally left blank.

## CHAPTER II PROGRAMMER'S REFERENCE

## INTRODUCTION

The 6052/6053 display terminals consist of two independent I/O devices, a keyboard console as the input device and an alphanumeric CRT display as the output device. The keyboard transmits and the display responds to a subset of the 128-ASCII character set listed in Appendix A.

Because the keyboard and the display function as independent devices, the program must echo the characters received from the keyboard if these characters are to be displayed as they are typed. The table at right summarizes the programming instructions and conventions used when the terminals operate with one of Data General's basic I/O asynchronous controllers.

## Keyboard


When a code-generating key is struck on the main, numeric or screen management keypads, an 8-bit code consisting of 7 data bits and 1 parity bit is transmitted to the computer. Appendix A lists the ASCII character codes generated by these keypads.

#### **User Function Codes**

When a user function key is struck a sequence of two codes is transmitted to the computer. The first code of the sequence is the ASCII control character Record Separator ( $036_8$ ). The second code is the appropriate ASCII character generated by the user function key. These codes are listed in Appendix B.

## – PROGRAMMING SUMMARY –

Mnemonic (First Controller) Input Output	ττι ττο	
Device Code (First Controller) Input Output	10 <sub>8</sub> 11 <sub>8</sub>	
Mnemonic (Second Controller) Input Output	TTI1 TTO1	
Device Code (Second Controller) Input Output	50 <sub>8</sub> 51 <sub>8</sub>	
Priority Mask Bit Input Output	14 15	
Characters per Line	80	
Lines per Display	24	
Total Storage Capacity (Characters)	1920	
Data Transfer Rate Max (Baud)	19,200	
ACCUMULATOR FORMATS		
Read Character Buffer	(DIA)	



## Display

The display responds to ASCII character codes received from the computer which contain 7 data bits and a parity bit. The parity computation for received data must be the same as that selected for the terminal by the setting of the parity switch. When either a parity or framing error occurs in a code received by the display, a question mark is displayed on the screen of the 6052 terminal and a 5x7 block is displayed on the screen of the 6053 terminal.

Printing characters received by the display are plotted on its screen (lower case characters received by the 6052 terminal display are plotted as their upper case equivalents). ASCII control characters representing display commands move the cursor around the screen, control blinking, dimming and underscoring of printing characters, erase information from the screen, and enable rolling of the screen. One command causes the display to transmit the current horizontal and vertical coordinates of the cursor to the computer. (Refer to the display commands described later in the text.) ASCII control characters which are not display commands are ignored by the display.

#### Character Blinking

The display unit of both terminals contains two flags, Blink and Blink Inhibit, which control the blinking of characters on the screen. These flags are set by the appropriate display commands. The current state of the Blink flag, 0 or 1, is stored in memory with each printing character as it is received. Thus, each memory location contains the character bits plus the blink bit. The display is blink enabled or disabled by the state of the Blink Inhibit flag. When it is blink enabled, each printing character whose blink bit is set to 1 is blinked on the screen; when it is blink disabled, none of the characters blink.

In addition to the appropriate blink display commands, each time an ERASE PAGE command is generated the blink flag is set to 0 and the display is blink enabled.

#### Character Dimming/Underscoring

The 6053 terminal display contains two flags, Dim and Underscore, which control the dimming and underscoring of printing characters. These flags are set by the appropriate display commands. The current state, 0 or 1, of both flags is stored in memory with each printing character as it is received. Thus, each memory location in the 6053 display contains the character bits, the blink bit, the dim bit and the underscore bit. Each printing character whose dim bit is set to 1 is displayed at reduced intensity; each printing character whose underscore bit is set to 1 is underscored on the screen.

In addition to the appropriate dim and underscore commands, each time an ERASE PAGE command is generated, both flags are set to 0.

#### Screen Rolling

The display unit of both terminals contains a Roll Enable flag, which controls the rolling of the screen. This flag is set by the appropriate display commands. When the display is roll enabled, the screen rolls up one line each time the cursor overflows the bottom line or a New Line code is received when the cursor is on the bottom line. When the display is not roll enabled, the cursor moves to the first character position on the top line each time the cursor overflows the bottom line or a New Line code is received when the cursor is on the bottom line.

The ERASE PAGE command does not affect the Roll Enable flag.

#### **Cursor Addressing**

The non-destructive cursor defines the location in memory where a character is stored and subsequently the position on the screen where it is displayed. The cursor is moved around the screen in two ways. It is moved relative to its current position (e.g., up, down, left or right). And, it is moved by sending a WRITE CURSOR ADDRESS command to the display followed by two binary codes containing the new cursor 7-bit column and 5-bit row address, respectively.

#### **Cursor Sensing**

The current position of the cursor is requested by sending a READ CURSOR ADDRESS command to the display. When this occurs, the terminal transmits a three-code sequence to the computer. The first code of the sequence is the ASCII control character Unit Separator ( $037_8$ ), the second is the cursor's 7-bit column address, and the third is the cursor's 5-bit row address. The program retrieves this information by issuing data in instructions to the keyboard.

## DISPLAY COMMANDS

The display commands are described in the following format:

COMMAND NAME (octal command code)

Function: Functional description

6052 Keyboard:	6053 Keyboard:		
Ways to generate on	Ways to generate on	6052 Keyboard:	6053 Keyboard:
main keypad	main keypad	CTRL-SHIFT-L	CTRL-\ , CTRL-SHIFT-\

#### ENABLE BLINK (0038)

Function: Each character whose blink bit contains a 1 is blinked on the CRT screen.

6052 Keyboard:	6053 Keyboard:	6052 Keyboard:	6053 Keyboard:
CTRL-C, CTRL-SHIFT-C	CTRL-C. CTRL-SHIFT-C		•
OTRE-0, OTRE-SITE 1-0	0110-0,0110-0111-1-0	CTRL-SHIFT-M	CTRL-SHIFT-1

#### DISABLE BLINK (004<sub>8</sub>)

Function: None of the characters displayed on the screen are blinked.

6052 Keyboard:	6053 Keyboard:
CTRL-D, CTRL-SHIFT-D	CTRL-D, CTRL-SHIFT-D

#### START BLINK (016<sub>8</sub>)

Function: The blink bit of each succeeding printing character received is set to 1. When the display is blink enabled, each character whose blink bit contains a 1 is blinked on the screen.

6052 Keyboard:	6053 Keyboard:
CTRL-N, CTRL-SHIFT-N	CTRL-N, CTRL-SHIFT-N

#### END BLINK (017<sub>8</sub>)

Function: The blink bit of each succeeding character received is set to 0.

6052 Keyboard: CTRL-O. CTRL-SHIFT-O

6053 Keyboard: CTRL-O. CTRL-SHIFT-O

#### **START DIM (034**8)

This command applies to the 6053 terminal only. While the 6052 terminal's keyboard can transmit this command, its display cannot respond to it.

Function: The dim bit of each succeeding printing character received is set to 1. Each character whose dim bit contains a 1 is displayed at reduced intensity (dimmed) on the screen.

#### END DIM (035<sub>8</sub>)

Function: The dim bit of each succeeding printing character received is set to 0.

6052 Keyboard:	6053 Keyboard:
CTRL-SHIFT-M	CTRL-SHIFT-1

#### START UNDERSCORE (024<sub>8</sub>)

This command applies to the 6053 terminal only. While the 6052 terminal's keyboard can transmit this command, its display cannot respond to it.

Function: The underscore bit of each succeeding printing character received is set to 1. Each character whose underscore bit is set to 1 is underscored on the screen.

6052 Keyboard: 6053 Keyboard: CTRL-T,CTRL-SHIFT-T CTRL-T,CTRL-SHIFT-T

#### END UNDERSCORE (025<sub>8</sub>)

Function: The underscore bit of each succeeding printing character received is set to 0.

6052 Keyboard:	6053 Keyboard:
CTRL-U, CTRL-SHIFT-U	CTRL-U, CTRL-SHIFT-U

#### BELL (007<sub>8</sub>)

Function: A short audible tone is produced on the speaker located in the display unit.

6052 Keyboard:	6053 Keyboard:
CTRL-G,CTRL-SHIFT-G	CTRL-G,CTRL-SHIFT-G

#### HOME (0108)

Function: The cursor moves to the first (leftmost) character position on the top line of the screen, which is the cursor home position.

6052 Keyboard: CTRL-H,CTRL-SHIFT-H Screen Management Keypad: HOME 6053 Keyboard: CTRL-H,CTRL-SHIFT-H Screen Management Keypad: HOME

#### **NEW LINE (012<sub>8</sub>)**

Function: The cursor moves to the first character position on the next line of the screen. If the cursor is on the bottom line, it moves to the home position, unless the terminal is roll enabled (refer to the ROLL ENABLE command described below.)

6052 Keyboard:	6053 Keyboard:
NEW LINE, SHIFT-NEW LINE,	NEW LINE, SHIFT-NEW LINE,
CTRL-NEW LINE,	CTRL-NEW LINE,
CTRL-SHIFT-NEW LINE,	CTRL-SHIFT-NEW LINE,
CTRL-J,CTRL-SHIFT-J	CTRL-J,CTRL-SHIFT-J

#### ERASE TO END OF LINE (013<sub>8</sub>)

Function: The screen clears from the position of the cursor to the end of the line on which the cursor resides.

6052 Keyboard:6053 Keyboard:CTRL-KCTRL-K,CTRL-SHIFT-KScreen Management Keypad:Screen Management Keypad:ERASE EOLERASE EOL

#### ERASE PAGE (014<sub>8</sub>)

Function: The screen clears and the cursor moves to the home position. Additionally, this command performs an End Blink, Enable Blink, End Dim (model 6053) and End Underscore (model 6053) operation.

6052 Keyboard: CTRL-L Screen Management Keypad: ERASE PAGE 6053 Keyboard: CTRL-L,CTRL-SHIFT-L Screen Management Keypad: ERASE PAGE

#### CARRIAGE RETURN (015<sub>8</sub>)

Function: The cursor moves to the first character position on the line on which the cursor resides.

6052 Keyboard: CR.CTRL-CR,CTRL-M SHIFT-CR,CTRL-SHIFT-CR 6053 Keyboard: CR,CTRL-CR,CTRL-M SHIFT-CR,CTRL-SHIFT-CR CTRL-SHIFT-M

#### WRITE CURSOR ADDRESS (020<sub>8</sub>)

Function: The display is forced to use the next two codes received as the cursor's new 7-bit column address and 5-bit line address, respectively. Both the columns and lines are numbered beginning with column 0, line 0. The columns are numbered from left to right across the screen; the lines are numbered from top to bottom. After the second character is received, the cursor moves to the location on the screen specified by the new coordinates.

6052 Keyboard:	6053 Keyboard:
CTRL-P	CTRL-P,CTRL-SHIFT-P

#### **READ CURSOR ADDRESS (005<sub>8</sub>)**

Function: A sequence of three codes is sent from the display to the computer. The first code is the ASCII control character, Unit Separator (US,  $037_8$ ); the second is the cursor's current 7-bit column address; and the third is the cursor's current 5-bit line address.

6052 Keyboard: 6053 Keyboard: CTRL-E,CTRL-SHIFT-E CTRL-E,CTRL-SHIFT-E

#### ROLL ENABLE (022<sub>8</sub>)

Function: The display is roll enabled; that is, the screen rolls up one line each time either the cursor overflows the bottom line or a New Line character is decoded when the cursor is on the bottom line. When this occurs, the cursor moves to the first character position on the bottom line, the bottom line becomes blank, and the information previously displayed on the top line is lost.

6052 Keyboard:6053 Terminal:CTRL-R,CTRL-SHIFT-RCTRL-R,CTRL-SHIFT-R

#### ROLL DISABLE (023<sub>8</sub>)

Function: The roll enable mode is terminated. When the display is not roll enabled, the cursor moves to the home position each time either the cursor overflows the bottom line or a New Line code is decoded when the cursor is on the bottom line. While the cursor position changes, the information displayed on the screen remains unchanged.

6052 Keyboard:	6053 Keyboard:
CTRL-S,CTRL-SHIFT-S	CTRL-S,CTRL-SHIFT-S

#### CURSOR UP $(027_8)$

Function: The cursor moves up one line while remaining in the same column position. If the cursor is on the top line, it moves to the bottom line of the screen.

6052 Keyboard:	6053 Keyboard:
CTRL-W,CTRL-SHIFT-W	CTRL-W,CTRL-SHIFT-W
Screen Management Keypad:	Screen Management Keypad:
<b>∔</b>	4

#### CURSOR RIGHT (030<sub>8</sub>)

Function: The cursor moves one character (column) position to the right. If the cursor is at the end of the line, a New Line operation is performed.

 6052 Keyboard:
 6053 Keyboard:

 CTRL-X,CTRL-SHIFT-X
 CTRL-X,CTRL-SHIFT-X

 Screen Management Keypad:
 Screen Management Keypad:

#### CURSOR LEFT (031<sub>8</sub>)

Function: The cursor moves one character position to the left. If the cursor is in the leftmost position on the line, it moves to the rightmost position and a Cursor Up operation is performed.

6052 Keyboard: CTRL-Y,CTRL-SHIFT-Y Screen Management Keypad: 6053 Keyboard: CTRL-Y,CTRL-SHIFT-Y Screen Management Keypad:

#### CURSOR DOWN (032<sub>8</sub>)

Function: The cursor moves down one line while remaining in the same column position. If the cursor is on the bottom line, it moves to the top line.

6052 Keyboard:	6053 Keyboard:
CTRL-Z,CTRL-SHIFT-Z	CTRL-Z,CTRL-SHIFT-Z
Screen Management Keypad:	Screen Management Keypad:
+	+
$\mathbf{PRINT} \ (021_{8})$	

This command applies to terminals equipped with either a model 6054 or 6055 printer option.

Function: Information displayed on the CRT Screen, beginning with the leftmost character on the cursor line and ending with the rightmost character on the bottom line, is printed. During the print operation, the keyboard is disabled.

6052 Keyboard CTRL-Q, CTRL-SHIFT-Q Screen Management Keypad PRINT 6053 Terminal: CTRL-Q, CTRL-SHIFT-Q Screen Management Keypad PRINT

#### PRINT FORM (001<sub>8</sub>)

This command applies to the 6053 terminal equipped with either a model 6054 or 6055 printer option. It can be used for data entry with pre-printed forms.

Function: This command is the same as the PRINT command described above, except that dimmed characters are interpreted as spaces. Only characters displayed at full intensity are transmitted to the printer.

6052 Keyboard CTRL-A, CTRL-SHIFT-A Screen Management Keypad SHIFT-PRINT 6053 Keyboard CTRL-A, CTRL-SHIFT-A Screen Management Keypad SHIFT-PRINT

## INSTRUCTIONS

The following intructions and timing information apply when the display terminals are used in conjunction with Data General's 4010 controller.

The 4010 controller contains an 8-bit input buffer and an independent 8-bit output buffer. Since the keyboard and display function as independent devices, one set of Busy and Done flags is available for input operations and another set for output operations.

The controller's Busy and Done flags are controlled using two of the device flag commands as follows:

- f=S Sets Busy to 1, Done to 0 and either reads a character into the input buffer or writes the character in the output buffer into the display's memory.
- f=C Sets Busy and Done to 0 and terminates all data transfer operations. A Clear command issued during a transfer will result in the partial reception of the code being transferred.
- f=P No effect.

## **Read Character Buffer**

DIA [f] ac, TTI

0	1	1	Α	C	0	0	1	]	F	0	0	1	0	0	0
0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15

The contents of the input buffer are placed in bits 8-15 of the specified AC. Bits 0-7 of the specified AC are set to 0. After the data transfer, the controller's input Busy and Done flags are set according to the function specified by F. The format of the specified AC is as follows:

							P7	ARLI	Y						
									СН	ARA	CTE	R OF	CO	MMA	ND
0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15

Bits	Name	Contents
0-7		Reserved for future use.
8	Parity	Parity bit selected at the terminal: even, odd or mark.
9-15	Character	The 7-bit character code read from the input buffer.

## Load Character Buffer

#### DOA [f] ac, TTO

0	1	1	Α	С	0	1	0	F		0	0	1	0	0	1
0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15

Bits 8-15 of the specified AC are loaded into the output buffer. After the data transfer, the controller's output Busy and Done flags are set according to the function specified by F. The format of the specified AC is as follows:

 CHARACTER OR COMMAND

 0
 1
 2
 3
 4
 5
 6
 7
 8
 9
 10
 11
 12
 13
 14
 15

Bits	Name	Contents				
0-7		Reserved for future use.				
8	Parity	Even, odd or mark parity. Tested by the display.				
9-15	Character	The 7-bit character code transmitted to the output buffer.				

## PROGRAMMING

Since the terminal is actually two separate devices, input and output are discussed separately.

#### Input

Striking any code-generating key or key combination, code-generating key plus CTRL and/or SHIFT, transmits a serial code containing 7 data bits and a parity bit to the controller. The controller assembles the data and parity bits into an 8-bit parallel code in its input buffer. When the code is fully assembled, the controller's input Busy flag is set to 0, its input Done flag is set to 1, and a program interrupt request is initiated. The program reads the character in the input buffer by issuing a READ CHARACTER BUFFER instruction (DIA) to the keyboard (TTI), after which it sets the Done flag to 0 by issuing a Start or Clear flag command. This allows the next character assembled in the controller's input buffer to generate a program interrupt request.

#### Output

The program sends a character to the controller's output buffer by issuing a LOAD CHARACTER BUFFER instruction (DOA) to the display (TTO). A Start flag command initiates a parallel to serial conversion and transmits the code to the display. While the character is being transmitted, the output Busy flag is set to 1 and the output Done flag is set to 0. When the transmission is completed, the output Busy flag is set to 0, the output Done flag is set to 1, and a program interrupt request is initiated.

Each time the program sends a character to the display, the output buffer must be reloaded with a LOAD CHARACTER BUFFER instruction. A sequence of LOAD CHARACTER BUFFER instructions together with Start flag commands transmit a multi-character message. The program must allow each character to be transmitted before sending another character to the controller's output buffer.

## TIMING CONSIDERATIONS

#### Input

After the controller's input Done flag is set to 1, the character in the input buffer is available to the program for a time interval determined by the baud rate before another key strike can destroy the character. To avoid possible data loss, the program must respond to the program interrupt request and read the character within the time interval indicated in the following table.

Baud Rate	Maximum Allowable Programmed I/O Latency (ms)
110	21.59
150	15.84
300	7.92
600	3.96
1,200	1.98
1,800	1.48
2,400	0.98
4,800	0.49
9,600	0.24
19,200	0.12

#### Output

After the controller's output Done flag is set to 1, the program should provide another character within a time period determined by the baud rate to keep the transmission line operating at its maximum rate.

Baud Rate	Time Limit (ms)
110	9,15
150	6.64
300	3.32
600	1.66
1,200	0.83
1,800	0.62
2,400	0.42
4,800	0.21
9,600	0.11
19,200	0.06

## **PROGRAMMING EXAMPLES**

The following examples show how a character passes from the keyboard to the computer and from the computer to the display. The first example reads a character from the keyboard, and the second example sends a character to the display.

## Example 1

The subroutine shown in example 3 is called by a JUMP TO SUBROUTINE instruction (JSR to TTYRD). It illustrates both reading and echoing characters, using AC0 to store the character.

### **Example 3**

## Subroutine to read and echo characters (interrupts disabled)

; TO DISPLAY

Read a c	haracter fi	rom the keyboard	TTYRD:	SKPDN	тті	;CHARACTER BUFFER : LOADED?
SKPDN	TTI	CHARACTER BUFFER		JMP	1	NO, TRY AGAIN
		; LOADED?		DIAC	0,TTI	;READ CHARACTER AND
JMP	1	;NO, TRY AGAIN				; CLEAR DONE
DIAC	O,TTI	;READ CHARACTER AND		SKPBZ	TTO	;DISPLAY FREE?
		; CLEAR DONE		JMP	1	;NO, TRY AGAIN
				DOAS	0, T T O	SEND CHARACTER

### Example 2

#### Send a character to the display

SKPBZ	TTO	DISPLAY FREE?
JMP	1	;NO, TRY AGAIN
DOAS	0, TTI	SEND CHARACTER TO
		; DISPLAY

## **Cursor Address Codes**

The cursor address is sent to the computer in response to a read cursor address code  $(005_8)$  received by the display. The address is contained in two codes of a three-code sequence. The first code of the sequence is always the cursor address header code  $(037_8)$ , the second is the 7-bit column address, and the third is the 5-bit row address.

Example 4 illustrates how cursor address codes can be retrieved from the data stream of an echo program. It uses the header code as a flag. When the flag is set, a counter is initialized and the next two characters read are stored in locations CCOL and CROW, respectively. CCOL and CROW are located in page zero of memory (first 377<sub>8</sub> locations), allowing global access to this information. After the second character is stored, the program jumps to a user-provided subroutine, called CADD in the example.

When a cursor address subroutine is not provided, the programmer should ensure that cursor address codes are not echoed to the display, since these codes will be interpreted as ASCII characters.

## Example 4

#### Read/echo characters and go to subroutine on receipt of cursor addresses (interrupts disabled)

	LOC 300 CADD		S OF USER CURSOR ADDRESS
	CCOL:	; SUBROL 0	;CURSOR COLUMN ADDRESS
	CROW:	0	; IS STORED HERE ;CURSOR ROW ADDRESS ; IS STORED HERE
	LOC 400		, to or oneb here
TTYRD;	LDA	1,CAHDR	;GET CURSOR ADDRESS ; HEADER CODE
	LDA	2,FLAG	INITIALIZE FLAG
START:	SKPDN	TTI	CHARACTER BUFFER
			; LOADED?
	JMP	1	NO, TRY AGAIN
	DIAC	O,TTI	READ CHARACTER AND
			; CLEAR DONE
	SUB#	0,1,SZR	;HEADER CODE?
	JMP	.+5	;NO
	MOV	0,2	;YES, SET FLAG
	LDA	3,CCNT	START COUNTER
	STA	3,ACNT	; ;
	JMP	START	;READ NEXT CHARACTER
	MOV#	2,2,SNR	;FLAG SET?
	JMP	.+8	;NO
	DSZ	ACNT	;YES, ROW ADDRESS?
	JMP	.+4	;NO, COLUMN ADDRESS
	STA	0,CROW	STORE ROW ADDRESS
	LDA	2,FLAG	;CLEAR FLAG
	JMP	@CADD	GO TO USER SUBROUTINE
	STA	0,CCOL	STORE COLUMN ADDRESS
	JMP	START	;READ NEXT CHARACTER
	SKPBZ	тто	;DISPLAY FREE?
	JMP	1	;NO, TRY AGAIN
	DOAS	0, TTO	;SEND CHARACTER TO ; DISPLAY
CAHDR	037		
FLAG:	0		
CCNT	2		
	-		

ACNT:

0

## **User Function Codes**

User function codes are received by the computer in a two-code sequence. The first code is always the user function header ( $036_8$ ); the second is an ASCII character whose function must be defined by the user program.

When a user function subroutine is not provided, the program should ensure that the ASCII characters representing function codes are not echoed to the display, since some of these characters will introduce data errors.

#### **Print and Print Form Codes**

When the display is equipped with a printer option, the PRINT  $(021_8)$  and PRINT FORM  $(001_8)$  codes must be echoed to the display. These codes are transmitted as user function sequences when they are generated by the PRINT key. Example 5 illustrates how user function codes, other than the PRINT and PRINT FORM codes, can be retrieved from the data stream of an echo program. It uses the header code as a flag. When the flag is set, the next character received is tested. If it is a PRINT or PRINT FORM code, the character is echoed. If it is not, the program ignores the character and waits for the character buffer to be loaded with the next character. When a print operation is started, keyboard input is disabled; when it is finished, the terminal sends an  $006_8$  code to the computer and the keyboard is reenabled.

## Example 5

LOC 400					
LDA	1,UFHDR				
		; HEADER CODE			
SKPDN	TTI	;CHARACTER BUFFER			
		; LOADED?			
JMP	1	;NO, TRY AGAIN			
DIAC	O,TTI	;READ CHARACTER AND			
		; CLEAR DONE			
SUB#	0,1,SZR	;USER FUNCTION HEADER?			
JMP	.+3	;NO			
STA	0,FFLAG	;YES, SET USER			
		; FUNCTION FLAG			
JMP	START	;WAIT FOR NEXT			
		; CHARACTER			
LDA	,				
MOV		-			
-		;NO, ECHO CHARACTER			
		;YES, CLEAR FLAG			
_		;			
LDA		GET PRINT CODE			
SUB#					
JMP		;YES, ECHO IT			
LDA	1,PF	;NO, GET PRINT-FORM			
		; CODE			
SUB#		;IS CHAR PRINT-FORM?			
JMP	START	;NO, DO NOT ECHO			
		; USER FUNCTION CODE,			
		; IF NOT USED			
		TTO BUSY?			
JMP	1	;YES, WAIT FOR			
		; NOT BUSY			
		ECHO CHARACTER			
JMP	START	SET UP FOR			
		; NEXT CHARACTER			
036		USER FUNCTION HEADER			
		; CODE			
-		FUNCTION FLAG			
		PRINT CODE			
001		;PRINT-FORM CODE			
	LOC 400 LDA SKPDN JMP DIAC SUB# JMP STA JMP LDA MOV JMP SUBC STA LDA SUB# JMP LDA	LOC 400 LDA1,UFHDRSKPDNTTIJMP1 0,TTIDIAC0,TSZR .+3 STAJMPSTARTJMPSTARTLDA1,FFLAG 1,1,SNR ECHO SUBCJMP1,FFLAG 1,1,SNR ECHO SUB# JMPSUB# JMP0,1,SZR 1,1,SNR ECHO 1,PR SUB# JMPSUB# JMP0,1,SZR 2,TARTSKPBZ JMPTTO 1DOAS JMP0,TTO STARTO360 021			

### **Program Interrupt**

The display terminals can be programmed using the program interrupt facility. This technique is useful in cases where a number of calculations can be performed in the time between receipt of characters in the input buffer.

The routine shown in example 6 reads a line, stores the characters in memory beginning at location  $1000_8$ and echoes them to the display using the interrupt priority structure. The user function header is used as a flag for user function codes. Both the header and the function code are stored in memory but are not echoed to the display. Cursor address sequences are handled in a manner similar to example 4 above. The program is terminated by a New Line code, a line overflow, or a cursor address sequence.

	•				SIA	1,CFLAG	;
					JMP	@CADD	GO TO USER SUBROUTINE
Example 6					STA	0,CCOL	STORE COLUMN ADDRESS
Liample o				JMP	OUT	WAIT FOR NEXT CHARACTER	
	Pead	a line usin	ig interrupts				
	ncau	a mic usm	ig interrupts		STA	0,@23	STORE CHARACTER IN BUFFER
	LOC 0				LDA	1,UFHDR	GET USER FUNCTION HEADER
	0 ;PC IS STORED HERE WHEN AN ; INTERRUPT OCCURS			SUB#	0,1,SZR	USER FUNCTION HEADER	
				JMP	.+3	;NO	
	IHAND				STA	0,FFLAG	YES. SET USER FUNCTION FLAG
		,ADDRES	ADDRESS OF INTERRUPT HANDLER		JMP	OUT	WAIT FOR NEXT CHARACTER
	LOC 300				LDA	1,FFLAG	FLAG SET?
	CADD	ADD ; ADDRESS OF USER CURSOR					
	; ADDRESS SUBROUTINE			MOV	1,1,SNR	;	
	CCOL:	0	;CURSOR COLUMN ADDRESS		JMP	.+4	;NO
			; IS STORED HERE		LDA	1,FLAG	;YES, CLEAR FLAG
	CROW:	0	CURSOR ROW ADDRESS		STA	1,FFLAG	;
	011011	Ū	; IS STORED HERE		JMP	OUT	;DO NOT ECHO USER
	100 400		, IS STONED HERE				FUNCTION CODE
	LOC 400				SKPBZ	тто	MAKE SURE TTO NOT BUSY
START:	LDA	1,BUFFR	SET UP BUFFER POINTER IN				, MARE SOME ITO NOT BOST
	STA	1,23	; AUTO-INCREMENT		JMP	1	
			; LOCATION 23		DOAS	0,TTO	;ECHO CHARACTER
	LDA	1.MAXLL	GET MAXIMUM LINE LENGTH		LDA	1,NL	;IS IT A NEW LINE?
	STA	1,CNTR	INITIALIZE LINE		SUB#	0,1,SZR	;
	014	1,01111	; OVERFLOW COUNTER		JMP	+4	;NO
	0.0070				SUBC	0,0	YES, CLEAR ACO WITHOUT
	SUBZL	1,1	;SET AC1 = 1			-,-	CHANGING CARRY
	DOBS	1,CPU	;MASK OUT TTO AND		STA	0.CNTR	ZERO OUT CNTR TO
			; TURN ON INTERRUPTS		STA	U,CINTR	
	-		;				; INDICATE LINE DONE
	-		PROGRAM CAN DO USEFUL		JMP	.+3	
			; THINGS WHILE LINE IS		DSZ	CNTR	;IF NOT A NEW LINE,
			; BEING READ				; DECREMENT CNTR
			, DEING READ		JMP	OUT	LINE NOT YET DONE,
	-						; GO DISMISS
HANG:	LDA	0,CNTR	;WHEN NEED FULL LINE TO		LDA	OTTMEK	LINE IS DONE
			CONTINUE,			0	
	MOV#	0,0,SZR	; HANG UP		MSKO	0	(MASK OUT TTI (AND TTO)
	JMP	2	; HERE UNTIL READING				; TO INHIBIT INPUT
	-		; IS ALL DONE	OUT:	LDA	0, <b>SAV</b> 0	;RESTORE ACCUMULATORS
	_		, IO ALL DOINE		LDA	1,SAV1	
					INTEN		; TURN INTERRUPTS BACK ON
					JMP	@0	RETURN TO INTERRUPTED
BUFFR	777		BEGINS AT				PROGRAM
		; LOCATI		SAV0:	0		, , , , , , , , , , , , , , , , , , , ,
MAXLL:	120	;MAXIMU	IM OF 80 CHARACTERS				
		; PER LIN	E	SAV1:	0		
CNTR:	0	;LINE OVE	ERFLOW COUNTER	CAHDR:	037		
-	_			UFHDR:	036		
				NL:	012		
IHAND:	SKPDN	TTI	MAKE SURE TTI CAUSED	FLAG	0		
INAND.	SKEDIN			CFLAG:	0		
				FFLAG	0		
	HALT		;ERROR, SOME OTHER	CCNT:	2		
			; PERIPHERAL INTERRUPTED				
	STA	0, <b>SAV</b> 0	SAVE ACCUMULATORS THAT	ACNT:	0		
			; WILL BE USED	TTMSK:	3		

STA

DIAC

LDA

SUB#

JMP

STA

LDA

STA

JMP

LDA

MOV

JMP

DSZ

JMP

STA

LDA

STA

1,SAVE1

READ CHARACTER AND

;SET CURSOR ADDRESS

;YES, ROW ADDRESS?

**;NO, COLUMN ADDRESS** 

**;STORE ROW ADDRESS** 

**;START COUNTER** 

;CURSOR ADDRESS HEADER?

WAIT FOR NEXT CHARACTER

; CLEAR DONE

1,CAHDR ;GET CURSOR ADDRESS

; HEADER

;NO

;NO

; FLAG

;FLAG SET?

;CLEAR FLAG

O.TTI

0,1,SZR

0,CFLAG

1,CCNT

1,ACNT

1.CFLAG

1,1,SNR

0,CROW

1,FLAG

1.CFLAG

OUT

+9

ACNT

+5

.+5

This page intentionally left blank.

## CHAPTER III OPERATOR CONTROLS AND PROCEDURES

## INTRODUCTION

The 6052/6053 display terminals serve as a communications link between the operator and the computer. The keyboard is the input device, transmitting the information entered by the operator to the computer. The display is the output device, receiving information from the computer and displaying the alphanumerics on the CRT screen, which is formatted as 24 lines, 80 characters per line.

To display information entered in the keyboard, an echo program in the computer must transmit the keyboard characters as they are received to the display. Since the terminal operates in full-duplex mode at data transmission rates up to 19.2K baud, information can be sent to and from the computer simultaneously at high speeds. When operating with suitable software, the time delay between keyboard entry and display is almost imperceptible to the operator and the terminal appears to operate in a manner similar to an office typewriter.

## DISPLAY

ASCII character codes received by the display are decoded and classified into three categories:

- alphanumeric, printing characters which can be displayed on the CRT screen;
- control characters which represent commands to the display; and
- control characters other than display commands.

When the display receives an alphanumeric, printing character, that character is stored in memory and is displayed on the CRT screen. The location in memory where the character is stored, and subsequently the location on the screen where the character is displayed, is defined by the position of a pointer, called the cursor. The position of the cursor on the screen is represented by a blinking underscore. After a character is entered in memory and displayed, the cursor moves one character position to the right. If the cursor is at the end of a line, it moves to the beginning of the next line. If the cursor is at the end of the bottom line on the screen, it moves to the beginning of the top line, unless the display is roll enabled. When the display is roll enabled, the screen rolls up one line each time the cursor overflows the bottom line or a New Line code is decoded when the cursor is on the bottom line. In this case, the cursor moves to the first character position on the bottom line, the bottom line becomes blank, and the information previously displayed on the top line is lost.

When the display receives a control character which represents a command to the display, the command is carried out. These commands manipulate the display's memory by moving the cursor, adding blink, dim (model 6053) and/or underscore (model 6053) attributes to designated characters, and clearing areas of the screen. A READ CURSOR ADDRESS command causes the current cursor column and row address to be transmitted to the computer.

When the display receives a control character which is not a display command, that character is ignored.

Appendix A lists the characters displayed by both the 6052 and 6053 terminals, the display commands and control characters which are not display commands.

## **KEYBOARD**

The keyboard consoles of both terminals contain four keypads: main, numeric, screen management and user function.

## Main Keypad

The 6052 terminal has a teletypewriter-style, 52-key, main keypad. This keypad transmits the 64 upper case graphic members of the ASCII character set. The 6053 terminal has a typewriter-style, 56-key, main keypad. This keypad transmits the 96 upper/ lower case graphic members of the ASCII character set. Both main keypads transmit 30 ASCII control characters.


With the exception of the CTRL, SHIFT, REPT (model 6052 only) and BREAK (model 6052 only) keys, each key on the main keypad generates a single

code when struck. On the 6053 keyboard, the REPT and BREAK keys reside on the screen management keypad; however, the function of these keys is identical on both models.


The CTRL and SHIFT keys do not generate codes when pressed alone; rather, they are used separately and in conjunction to alter the code produced by most code-generating keys.

The REPT key does not generate a code when pressed alone; however, when this key is pressed in conjunction with a code-generating key, the resulting code is repeated until one of the keys is released.

The BREAK key, when pressed, places the transmission line in a spacing state. While this key is pressed other key-entered codes are not transmitted. When the display terminal is equipped with a printer option, pressing this key aborts a print operation.




#### - 6053 TERMINAL MAIN KEYBOARD



## Numeric Keypad

The numeric keypads of both terminals are the same. Each contains 11 keys which generate the ASCII codes for the numerals 0 through 9 plus the period character. This keypad is arranged like a ten-key adding machine for ease in entering numeric data.




## Screen Management Keypad


The screen management keypads of both terminals are the same, except that the REPT and BREAK keys are added on the 6053 terminal.

The four keys marked with arrows move the cursor in the direction indicated. The HOME key moves the cursor to the leftmost character position on the top line of the screen. The ERASE PAGE key clears the screen and moves the cursor to the home position. The ERASE EOL key clears the characters on the screen from the position of the cursor to the end of the line on which the cursor resides.

The unlabeled key is an additional user function key. See the User Function Keypad. The PRINT key is also a user function key when the terminal is not equipped with a printer option. When it is, pressing this key places the terminal in print mode and the keyboard is disabled until the print operation is completed.


The use of the TAB key must be defined by the program; otherwise, the code generated by this key is ignored when it is received by the display.





#### **User Function Keypad**

The user function keypads of the 6052 and 6053 terminals consist of 8 and 11 keys, respectively. Each key, when pressed, generates a two-code sequence. The first code of the sequence is the ASCII control character RS (Record Separator,  $036_8$ ). When this code is received by the computer, it notifies the executing program that the next character received is a user-defined control character. The codes generated by these keys are listed in Appendix B.



## **DISPLAY EXTERNAL CONTROLS**

## **Front Panel**

#### **Power ON/OFF and Screen Brightness**

The power switch and CRT screen brightness control are combined in a single control knob. Pulling this knob out turns the display terminal power on; pushing it in turns the power off. Rotating the knob clockwise makes the screen image brighter; rotating it counter-clockwise makes it darker.

#### **Rear Panel**

#### Data Rate

The data transmission rate is selected by moving the DATA RATE rotary switch to one of its ten positions. The baud rate selected by each position is marked on the panel.

#### Parity


The parity computation performed by the display terminal is selected by moving the PARITY slide switch to one of its three positions: EVEN, ODD or in the center, unmarked position for mark parity.

#### Mode

The operating mode of the terminal is selected by moving the MODE slide switch to one of its two positions: LINE or LOCAL. In LINE mode, information entered in the keyboard is transmitted to the computer and information received from the computer is sent to the display. In LOCAL mode, information entered in the keyboard is sent directly to the display and the display does not receive information from the computer.

#### Screen

The operator can position the display screen by moving it in both a horizontal and vertical direction. This feature can reduce operator fatigue.



## **OPERATING NOTE**

**CAUTION** - Do not cover the ventilation openings in the top cover of the display unit as operating failure due to overheating may occur.

## CLEANING

Wipe the external surfaces of the keyboard console and the display unit with a soft, dry, lint-free cloth. If necessary, clean the covers with a soft cloth dampened with a mild detergent solution, rinse with a soft cloth dampened with water, and buff dry.

Clean the screen by wiping the surface with a soft, lint-free cloth dampened with either water or a window-cleaning solution, such as Windex.

## **PREVENTIVE MAINTENANCE**

The display diagnostic tape and listing, Nos. 095-000477 and 096-000477, respectively, are included in the documentation package. This test can be run on an "as needed" basis.

This page intentionally left blank.

1

.

.

1

# APPENDIX A ASCII CHARACTER CODES WITH TERMINAL CONTROL FUNCTIONS

LEGEND:

64

0

@

CHARACTER CODE IN DECIMAL

													EBCDIC EQ	UIVA	ALENT HEX	KADI	CIMAL CO	DE		70	<u> </u>
	1 means CONTROL CHARACTER																				
ост	AL.		00_		ONTROL JNCTION		01_		ONTROL INCTION		02_	C FL	ONTROL		03_		ONTROL JNCTION	Τ	04	Ι	05
	0	0 00	NUL		NULL	8 16	BS (BACK- SPACE)		HOME	16 10	DLE 1P	c	WRITE URSOR IEADER	24 18	CAN 1X	Ī	CURSOR RIGHT	32 40	SPACE	40 4D	(
	1	1 01	sон 1А	PR	RINT FORM	9 05	НТ ( <i>тав)</i>	но	RIZONTAL TAB	17 11	DC1 1ַQ	PR	INT PAGE	25 19	EM 1Y		CURSOR LEFT	33 5A	!	41 5D	)
	2	2 02	sтх 1́В		START OF TEXT	10 15	NL (NEW LINE)	12	IEW LINE	18 12	DC2 1R	R	OLL ON	26 3F	SUB 1Z		CURSOR DOWN	34 7#	,, (QUOTE)	42 5C	*
	3	3 03	ETX 1C	٦ ENA	ABLE BLINK	11 013	VT (vert. tab)	EF	RASE LINE	19 13	DC3 1S	R	OLL OFF	27 27	ESC (ESCAPE)		ESCAPE	35 78	#	43 4E	+
	4	4 37	еот 1́D	INH	IBIT BLINK	12 06	FF (Form FEED)	ER.	ASE PAGE	20 3C	DC4 1॒T	UNI	OERSCORE	(a) 10	FS 1\		DIM ON	36 58	\$	44 68	(COMMA)
	5	5 2D	ENQ 1E		CURSOR ADDRESS READ	13 0D	RT (return)	!	RETURN	21 3D	NAK 1U	UNE	DERSCORE OFF	(a) 10	cs 1]		DIM OFF	37 6C	%	45 60	-
	6	6 2E	аск 1₽	PR	NINT DONE	14 0E	so 1N	B	ILINK ON	22 32	SYN ⊥V	SYN	CHRONOUS IDLE	30 1E	<b>RS</b> <u>1</u> ↑		CTION KEY HEADER	38 50	&	46 48	(PERIOD)
	7	7 2F	BEL <u>†</u> G		BELL	15 0F	sı 10	BI	LINK OFF	23 26	ETB ⊥W	сι	JRSOR UP	31 1/*	Us 1←		READ URSOR IEADER	39 7D	, (APOS)	<b>47</b> 61	/
	,									<del></del>											
ост. 	AL		06		07		10_		11_		12		13_		14		15		16		17
	0	48 F0	Ø	56 F8	8	64 7C	@	72 C8	н	80 D7	Р	88 E7	x	96 79	、 (GRAVE)	104 88	h	112 97	þ	120 A7	x
	1	49 F1	1	57 F9	9	65 C1	Α	73 C9	1	81 D8	٥	89 E3	Y	97 81	а	105 89	i	113 98	q	121 AB	Y
	2	50 F2	2	58 7A	:	66 C2	В	74 D1	J	82 D9	R	90 E9	Z	98 82	b	106 91	j	114 99	r	122 A9	z
	3	51 F3	3	59 5E	;	67 C3	С	75 D2	к	83 E2	S	91 6D	[	99 83	С	107 92	k	115 A2	S	123 C0	{
	4	52 F4	4	60 4C	<	68 C4	D	76 D3	L	84 E3	Т	92 E0	\	1.00 84	d	108 93	I	116 A3	t	124 4F	
	5	53 F5	5	61 7E	=	69 65	E	77 D4	М	85 E4	U	93 9D	]	101 85	е	109 94	m	117 A4	u	125 D0	}
	6	54 F6	6	62 6E	>	70 C6	F	78 D5	N	86 E5	v	94 5F	$\uparrow \stackrel{\mathbf{or}}{\wedge} 0$	102 86	Ì	110 95	n	118 A5	v	126 A 1	~ (TILDE)
	7	55 F7	7	63 6F	?	71 C7	G	79 D6	0	87- E6	Ŵ	95 6D	.← or	103 87	9	111 96	o	119 A6	. W	127 07	DEL (RUBOUT)

CHARACTER CODE IN OCTAL AT TOP AND LEFT OF CHARTS. DG-03384

		7 BIT	KEYPAD			
	SYMBOL DISPLAY	OCTAL CODE	MAIN KEYPAD	NUMERIC KEYPAD		
Space	Non-printing	040	Space Bar			
Exclamation Mark	1 !	041	SH 1	-		
Quotation Marks		042	SH 2	~		
Number Sign	#	043	SH 3	-		
Dollar Sign	\$	044	SH 4	-		
Percent	0.0	045	SH 5	-		
Ampersand	&	046	SH 6	-		
Apostrophe	,~	040	SH 7	-		
Opening Parenthesis	(	047		-		
Closing Parenthesis		050	SH 8	-		
Asterisk	*	052	SH 9	-		
Plus	+		SH :	-		
Comma		053	SH ;	-		
Hyphen (Minus)	•	054	•	-		
Period (Decimal Point)	-	055	-	-		
		056				
Slant		057	/	-		
Zero	0	060	0	0		
One		061	1	1		
Two	2	062	2	2		
Three	3	063	3	3		
Four	4	064	4	4		
Five	5	065	5	5		
Six	6	066	6	6		
Seven	7	067	7	7		
Eight	8	070	8	8		
Nine	9	070	9			
Colon		072	9	9		
Semicolon		072	:			
Less Than	<	1		-		
Equals	-	074	SH ,	-		
		075	SH	-		
Greater Than	?	076	SH .	-		
Question Mark		077	SH /	-		
Commercial At	@	100	SH P	-		
A	A	101	A, SH A	-		
В	B	102	B, SH B	-		
С	C	103	C, SH C	-		
D	D	104	D, SH D	_		
Е	E	105	E, SH E			
F	F	106	F, SH F	}		
G	G	107	G, SH G			
Н	Н	110	H, SH H	_		
1	I	111	I, SH I	-		
J	J	111	J, SH J	-		
ĸ	к	112	K	-		
L	L	113	L	-		
ы М	M	114		-		
N	N	1	M	-		
O	0	116	N	-		
	P	117	0	-		
Р	1	120	P	-		
Q	Q	121	Q. SH Q	-		
R	R	122	R, SH R	-		
S	S	123	S, SH S	-		
Т	Т	124	T, SH T	-		
U	U	125	U, SH U	-		
V	V	126	V, SH V	-		
w	W	127	W, SH W	-		
X	x	130	X, SH X	-		
Y	Y	131	Y, SH Y	-		
Ż	Z	132	Z, SH Z	_		
Opening Bracket		133	SH K	_		
Reverse Slant		134	SHL	1		
Closing Bracket		135	SH M	-		
		135	SH M SH N	-		
				-		
Underline	-	137	SHO	-		

## ASCII Character Codes Plotted by the 6052 Terminal

DG-03822

### ASCII Character Codes Plotted by the 6053 Terminal

	7 BIT SYMBOL OCTAL		KEY	PAD
NAME	DISPLAY		MAIN KEYPAD	NUMERIC KEYPAD
Space	Non-printing	040	Space Bar	
Exclamation Mark	1	041	SH 1	
Quotation Marks	,,	042	SH'	-
Number Sign	#	043	SH 3	-
	\$			-
Dollar Sign		044	SH 4	-
Percent		045	SH 5	-
Ampersand	&	046	SH 7	-
Apostrophe	, , ,	047	,	-
<b>Opening Parenthesis</b>	(	050	SH 9	-
Closing Parenthesis	)	051	SH 0	
Asterisk	*	052	SH 8	
Plus	+	053	SH =	
	1 1	054	311 -	-
Comma	, ,			-
Hyphen (Minus)	-	055	-	-
Period (Decimal Point)	· · ·	056		•
Slant	1	057	/	-
Zero	0	060	0	0
One		061	1	1
Two	2	062	$\frac{1}{2}$	2
Three	3	063	$\tilde{3}$	
				3
Four	4	064	4	4
Five	5	065	5	5
Six	6	066	6	6
Seven	7	067	7	7
Eight	8	070	8	8
Nine	9	071	9	9
Colon		072	SH ;	9
	:		SH;	-
Semicolon	1 : 1	073		-
Less Than	<	074	SH ,	-
Equals	=	075	=	-
Greater Than	>	076	SH.	_
Question Mark	?	077	SH/	
Commercial At	e .	100	SH 2	-
				-
A	A	101	SH A	-
В	В	102	SH B	-
С	С	103	SHC	-
D	D	104	SH D	-
E	Е	105	SH E	
F	F	106	SH F	
G	G	107	SHG	_
H	Н	110	SH H	-
I	Ĭ	110	SHI	·
-	-			-
J	J	112	SH J	-
К	К	113	SH K	-
L	L	114	SH L	-
Μ	M	115	SH M	
N	N	116	SH N	
0	0	117	SHO	
P	P	120	SH P	
		120	SHQ	i i
Q	Q			-
R	R	122	SHR	· ·
S	S	123	SHS	· ·
Т	Т	124	SH T	
U	U	125	SHU	
v	V	126	SH V	
Ŵ	Ŵ	127	SHW	
	X	130	SH W SH X	
X	V			
X Y Z	Y Z	131 132	SH Y SH Z	

		7 BIT OCTAL	KE	YPAD	
NAME	SYMBOL DISPLAY	CODE	MAIN KEYPAD	NUMERIC KEYPAD	
Opening Bracket	ſ	133	[	-	
Reverse Slant	N	134	N .	-	
Closing Bracket	]	135	]	-	
Circumflex	^	136	SH 6		
Underline		137	SH -		
Grave Accent		140	``		
a	8.	141	А	-	
b	b	142	B	-	
с	c	143	Ē	-	
d	d	144	D		
е	е	145	D E F G		
f	f	146	F	-	
g h	g	147	Ğ	-	
h	h	150	н	-	
i	i	151	I	-	
j	j	152	J	-	
k	k	153	К	-	
1	1	154	L	-	
m	m	155	M	-	
n	n	156	N	-	
0	0	157	0	-	
р	р	160	Р	-	
q	q	161	Q R	-	
r	r	162	R	-	
S	s	163	S	-1	
t	t	164	Т	-	
u	u	165	U	-	
v	v	166	V	-	
w	w	167	w	-	
x	x	170	X	-	
У	у	171	Y	-	
Z	z	172	Z	-	
Open Brace	{	173	{	-	
Vertical Line		174	SH\	-	
Closing Brace	}	175	SH{	-	
Tilde	~	176	SH`	-	

# ASCII Character Codes Plotted by the 6053 Terminal (Continued)

DG-03824

.

### DISPLAY COMMANDS

		MAINI	EYPAD	SCREEN	
NAME	OCTAL CODE	MODEL 6052	MODEL 6053	MANAGEMENT KEYPAD	FUNCTION
ENABLE BLINK	003	CTRL-C or CTRL-SHIFT-C	CTRL-C or CTRL-SHIFT-C	-	Blink characters whose blink bit is set to 1.
DISABLE BLINK	004	CTRL-D or CTRL-SHIFT-D	CTRL-D or CTRL-SHIFT-D	-	Disable character blinking
READ CURSOR ADDRESS	005	CTRL-E or CTRL-SHIFT-E	CTRL-E or CTRL-SHIFT-E	_	Cursor address header code, 037 <sub>8</sub> . followed by 2 codes containing 7-bit column and 5-bit row address, respectively, are sent to computer.
BELL	007	CTRL-G or CTRL-SHIFT-G	CTRL-G or CTRL-SHIFT-G	-	Short tone produced by speaker in display.
HOME	010	CTRL-H or CTRL-SHIFT-H	CTRL-H or CTRL-SHIFT-H	HOME	Cursor moves to first (leftmost) character position on top line of screen.
NEW LINE	012	NEW LINE, CTRL-NEW LINE, CTRL-SHIFT-NEW LINE, CTRL-J, or CTRL-SHIFT-J	NEW LINE, CTRL-NEW LINE, CTRL-SHIFT-NEW LINE, CTRL-J, or CTRL-SHIFT-J	-	Cursor moves to first character position on next line,
ERASE TO END OF LINE	013	CTRL K	CTRL-K or CTRL-SHIFT-K	EOL	Erase characters from and including the position of the cursor to the end of the line.
ERASE PAGE	014	CTRL-L	CTRL-L CTRL-SHIFT-L	EOP	Erase all characters on screen.
CARRIAGE RETURN	015	CR, CTRL-M, CTRL-CR, SHIFT-CR, or CTRL-SHIFT-CR	CR, CTRL-CR, SHIFT-CR, CTRL-SHIFT-CR, CTRL-M, or CTRL-SHIFT-M	-	Cursor moves to first character position on the line it is on.
START BLINK	016	CTRL-N or CTRL-SHIFT-N	CTRL-N or CTRL-SHIFT-N	_	Set blink bit to 1 in succeeding printing characters received.
END BLINK	017	CTRL-O or CTRL-SHIFT-O	CTRL-O or CTRL-SHIFT-O	-	Set Blink bit to 0 in succeeding printing characters received.
WRITE CURSOR ADDRESS	020	CTRL-P	CTRL-P or CTRL-SHIFT-P	-	Next 2 characters received are used as cursor's 7-bit column and 5-bit row address, respectively, and the cursor is moved accordingly.
ROLL ENABLE	022	CTRL-R or CTRL-SHIFT-R	CTRL-R or CTRL-SHIFT-R	_	Screen rolls up one line each time the cursor overflows the bottom line or a New Line code is received when the cursor is on the bottom line Cursor moves to first character position on bottom line.
ROLL DISABLE	023	CTRL-S or CTRL-SHIFT-S	CTRL-S or CTRL-SHIFT-S	-	When New Line code is received and the cursor is on the bottom line, the cursor moves to Home position,
START UNDERSCORE	024	CTRL-T or CTRL-SHIFT-T	CTRL-T or CTRL-SHIFT-T	-	Set Underscore bit to 1. Each succeeding printing character received is underlined on screen.(1)
END UNDERSCORE	025	CTRL-U or CTRL-SHIFT-U	CTRL-U or CTRL-SHIFT-U		Set Underscore bit to 0. Each succeeding printing character received is not underlined.(1)

DG-03825

DISPLA	Y CO	MMAN	DS, C	CONT.
--------	------	------	-------	-------

	0.0741	MAI	N KEYPAD	SCREEN		
NAME	OCTAL CODE	MODEL 6052	MODEL 6053	MANAGEMENT KEYPAD	FUNCTION	
CURSOR UP	027	CTRL-W or CTRL-SHIFT-W	CTRL-W or CTRL-SHIFT-W	ţ ţ	Cursor moves up one line while remaining in same column (character) position.	
CURSOR RIGHT	030	CTRL-X or CTRL-SHIFT-X	CTRL-X or CTRL-SHIFT-X		Cursor moves one character position to the right.	
CURSOR LEFT	031	CTRL-Y or CTRL-SHIFT-Y	CTRL-Y or CTRL-SHIFT-Y		Cursor moves one character position to the left.	
CURSOR DOWN	032	CTRL-Z or CTRL-SHIFT-Z	CTRL-Z or CTRL-SHIFT-Z	ļ	Cursor moves down one line while remaining in same character position	
START DIM	034	CTRL-SHIFT-L	CTRL-\ or CTRL-SHIFT-\	-	Set Dim bit to 1. Each succeeding printing character received is dimmed on the screen. (1)	
END DIM	035	CTRL-SHIFT-M	CTRL-SHIFT-]		Set Dim bit to 0. Each succeeding printing character received is displayed at full intensity on the screen. (1)	

(1) Model 6053 only Model 6052 display will not respond to these commands.

DG-03826

			MAIN KE	YBOARD		
NAME	STANDARD MNEMONICS	OCTAL CODE	MODEL 6052	MODEL 6053	SCREEN MGNT KEYBOARD	
NULL	NUL	000	CTRL-SHIFT-P	CTRL-SHIFT-2	_	
START OF HEADING	SOH	001	CTRL-A CTRL-SHIFT-A	CTRL-A CTRL-SHIFT-A	-	
START OF TEXT	STX	002	CTRL-B CTRL-SHIFT-B	CTRL-B CTRL-SHIFT-B	_	
ACKNOWLEDGE	АСК	006	CTRL-F CTRL-SHIFT-F	CTRL-F CTRL-SHIFT-F	_	
HORIZONTAL TAB	НТ	011	CTRL-I CTRL-SHIFT-I	CTRL-I CTRL-SHIFT-I	ТАВ	
DEVICE CODE 1	DC1	021	CTRL-Q CTRL-SHIFT-Q	CTRL-Q CTRL-SHIFT-Q	-	
SYNCHRONOUS IDLE	SYN	026	CTRL-V CTRL-SHIFT-V	CTRL-V CTRL-SHIFT-V	-	
ESCAPE	ESC	033	ESC CTRL-SHIFT-K	ESC CTRL-L	-	

### **PROTOCOL CHARACTERS**

NOTE: The protocol characters, Record Separator (036) and Unit Separator (037) cannot be generated by the keyboard. These codes are generated by the display hardware and are used as user function and cursor address header codes, respectively.

DG-03827

,

.

This page intentionally left blank.

.

# APPENDIX B CODE SEQUENCES GENERATED BY THE USER FUNCTION KEYPAD

SEQUENCE OF CODES	KEYS
036, 041	CTRL-SHIFT-[user function 1]
036, 042	CTRL-SHIFT-[user function 2]
036, 043	CTRL-SHIFT-[user function 3]
036, 044	CTRL-SHIFT-[user function 4]
036, 045	CTRL-SHIFT-[user function 5]
036, 046	CTRL-SHIFT-[user function 6]
036, 047	CTRL-SHIFT-[user function 7]
036, 050	CTRL-SHIFT-[user function 8]
036, 051	CTRL-SHIFT-[user function 9]*
036, 052	CTRL-SHIFT-[user function 10]*
036, 053	CTRL-SHIFT-[user function 11]*
036, 061	CTRL-[user function 1]
036, 062	CTRL-[user function 2]
036, 063	CTRL-[user function 3]
036, 064	CTRL-[user function 4]
036, 065	CTRL-[user function 5]
036, 066	CTRL-[user function 6]
036, 067	CTRL-[user function 7]
036, 070	CTRL-[user function 8]
036, 071	CTRL-[user function 9]*
036, 072	CTRL-[user function 10]*
036, 073	CTRL-[user function 11]*
036, 141	SHIFT-[user function 1]
036, 142	SHIFT-[user function 2]
036, 143	SHIFT-[user function 3]
036, 144	SHIFT-[user function 4]
036, 145	SHIFT-[user function 5]
036, 146	SHIFT-[user function 6]
036, 147	SHIFT-[user function 7]
036, 150	SHIFT-[user function 8]
036, 151	SHIFT-[user function 9]*
036, 152	SHIFT-[user function 10]*
036, 153	SHIFT-[user function 11]*
036, 161	[user function 1]
036, 162	[user function 2]
036, 163	[user function 3]
036, 164	[user function 4]
036, 165	[user function 5]
036, 166	[user function 6]
036, 167	[user function 7]
036, 170	[user function 8]
036, 171	[user function 9]*
036, 172	[user function 10]*
036, 173	[user function 11]*

Additional user-defined codes generated by Screen Management Keypad

036,001 036,002	SHIFT-PRINT** SHIFT-unmarked key
036, 021	PRINT**
036, 022	unmarked key

\*Denotes 6053 Display Terminal only.

\*\*When the display is not equipped with a Printer option. DG-03828 This page intentionally left blank.

## **READERS COMMENT FORM**

### DOCUMENT TITLE:

Your comments, accompanied by answers to the following questions, help us improve the quality and usefulness of our publications. If your answer to a question is "no" or requires qualification, please explain.

#### How did you use this publication?

- () As an introduction to the subject.
- () As an aid for advanced knowledge.
- () For information about operating procedures.
- () To instruct in a class.
- () As a student in a class
- () As a reference manual.
- () Other.....

#### Did you find the material:

- Complete.....YES ( ) NO ( )
- Accurate......YES () NO ()
- Well organized..... YES () NO ()
- Well written.....YES ( ) NO ( )
- Well illustrated......YES ( ) NO ( )
- Well indexed..... YES () NO ()
- Easy to read...... YES ( ) NO ( )
- Easy to understand..... YES ( ) NO ( )

We would appreciate any other comments; please label each comment as an addition, deletion, change, or error and reference page numbers where applicable.

#### COMMENTS

PAGE	COL.	PARA	LINE	FROM	το
L					
	·				

#### From:

NAME	TITLE	
FIRM	DIV	
ADDRESS		
СІТҮ	STATE	ZIP
TELEPHONE	DATE	

**Data General Corporation** 

ENGINEERING PUBLICATIONS COMMENT FORM DG-00935

CUT ALONG DOTTED LINE

FOLD DOV	NN	FIRST	FOLD DO	FOLD DOWN	
	DataG			FIRST CLASS PERMIT NO 26 SOUTHBORO MASS 01772	
	ATTENTIO	N: Engineering Pu	ıblications		

FOLD UP

SECOND

-------

FOLD UP

---------