	REVISION RECORD								
REV	ECO	DESCRIPTION	DRFT	DATE	CHKD	APPR			
A B	1963	RELEASE SELECT R22-1 VALUE	WJM	3/92	WM .	enl -			

## ACCEPTANCE TEST PROCEDURE

(ATP)

ZETAO

DIMENSIONS ARE IN INCHES UNLESS OTHERWISE SPECIFIED  Tolerances: 3Place 2Place Angles ±.005 ±01 ±30°	© 1990, Zetaco, Inc.	ATP,BMX-2		
DO NOT SCALE DRAWING	DWN WJM	DOCUMENT NO.	REV.	
This document contains confidential proprietary information of Zetaco,	CKD			
Inc. Neither the document or information therein is to be reproduced,	ENG	951-458-00	В	
distributed, used or disclosed, either in whole or in part except as speci-	MFG	1		
fically authorized by Zetaco, Inc.	APPR RAZ	SCALE SHEET	1 OF 3	

Printed: 03/30/92 Sheet 2 of 3

951-458-00 Rev: B

## ZETACO ACCEPTANCE TEST PROCEDURE

For: BMX-2

- 1. Clean gold board edge connectors.
- 2. Rap board to remove any foreign substance.
- 3. Insure that all socketed chips are installed properly. Verify that the PROMS/EEPROMS are of the correct speed per parts list and circuit requirements.
- 4. Power-up and insure that Self-test runs.
- 5. Put switch 1 in UP position.
- 6. Test the Power Fail circuit to insure switch level is between 4.60 4.74 volts.
- 7. Select the desired device code on switch.
- 8. Load BMX2CF and configure the board for 6026 emulation, and the type of drive you are using. (Must be Dual Density drive with Remote Density Select.)
- 9. Run BMX2D (set switch "J" for CDC 92185) 3 passes and verify BUSY LED works.
- 10. Run ZZMTRL 3 passes and verify DCH LED works.
- 11. Reconfigure board for 4307 emulation: BMC; BMC PRIORITY = 2; BURST RATE = 16; Auto Retry enabled.
- 12. Run BMX2D (set switch "J" for CDC 92185) 3 passes.
- 13. Run ZMTRL 3 passes and verify BMC LED works. Check pulse at C8-8. Change resistor R22-1 (location P10) as necessary to achieve 45ns to 55ns pulse width.
- 14. Change burst rate to 256 words.
- 15. Run BMX2R... 1 pass. (Shock test board and run margins at 4.75V and 5.25V.)

951-457-00 Rev: B

- 16. Boot DTOS and run prior X (run at Device Code 22).
- 17. Reconfigure board for 6026 emulation.
- 18. Remove BMC board from system.
- 19. Boot AOS and perform a DUMP/LOAD at high and low density with and 8K buffer size specified.
- 20. Configure board per customer configuration sheet.